



Part Number 75-106-4 V-Rod Outlaw Indy Series Exhaust System (All Years)

Congratulations, you have purchased the finest exhaust system available for your motorcycle. Your Vance & Hines Motorsports exhaust is designed and crafted for maximum performance, a great sound and unbeatable style. Please follow the instructions below, check exhaust system for missing or damaged parts and if you need any assistance please contact our technical support line (317) 852-9057.

IDENTIFY PASSENGER FOOTPEG MOUNTING LOCATION

Footpeg mount on swingarm - refer to early model removal instructions.
Footpeg mount on frame - refer to late model removal instructions.

STOCK EXHAUST SYSTEM REMOVAL (EARLY MODELS)

1. Loosen nose slip clamp at front of muffler section.
Note: WD-40 at the joint may assist in removal.
2. Remove pin located on mounting bracket from stock exhaust system using 13mm wrench and 4mm allen wrench.
3. Remove two 6mm allen bolts connecting lower muffler to mounting bracket.
4. Remove the entire muffler section from the head pipes as a single unit.
5. Remove nuts from both front and rear exhaust cylinder head flanges using a 13mm socket or wrench.
6. Remove the stock exhaust flanges and circlips from both the front and rear head pipes.

STOCK EXHAUST SYSTEM REMOVAL (LATER MODELS)

7. Loosen nose slip clamp at the front of the muffler section using a 13mm socket.
Note: WD-40 at the joint may assist in removal.
8. Remove the three 6mm allen bolts holding the muffler assembly to the bike.
Their locations are: rear footpeg mount, muffler to mounting bar and center of the muffler mounting bracket.
9. Remove the passenger footpeg from the frame to facilitate removal of muffler assembly.
10. Carefully remove muffler and collector assembly from motorcycle.
11. On models with O² sensors it will be necessary to disconnect the sensor wires from the wire harness.
12. Remove nuts from both front and rear exhaust cylinder head flanges using a 13mm socket or wrench.
13. Carefully remove head pipes from motorcycle.
14. Using a 7/8" or 22mm wrench, carefully remove the O² sensor from the stock head pipes and save for re-use with the new system.
15. Remove the stock exhaust flanges and circlips from both the front and rear head pipes.
16. Remove the stock mounting bar.
If the circlips are bent or twisted they should be replaced, Harley-Davidson part number #65045-01
We also recommend replacing the stock exhaust gaskets, Harley-Davidson part number #65109-01

INDY SERIES EXHAUST SYSTEM INSTALLATION

1. Identify front head pipe #7-80116. Install the stock flange and circlip, install head pipe leaving the flange nuts hand tight.
2. Repeat the above step for the rear head pipe #7-80117.
3. Slip the megaphone/collector assembly onto the head pipes, secure with the four springs supplied using the spring puller tool.
4. Rotate the exhaust so there is adequate clearance in all places.
Note: Models with mid control footpegs should check clearance between the break pedal and the megaphone with the break pedal fully depressed.
5. Tighten the cylinder head flange nuts for both the front and rear head pipes.
6. Tighten the O² plugs on the front and rear head pipes.
7. Models with O² sensors reinstall the O² sensors previously removed, refer to (Figure 1) for front cylinder and (Figure 2) for rear cylinder wire routing.



Figure 1



Figure 2

8. Make sure the oil line is not touching the front head pipe. If necessary, loosen the ties and rotate the oil line away from head pipe, retie the oil line to the fan mount.
9. On later models replace the passenger foot peg removed on step 9 from the later model removal instructions.
10. Clean all fingerprints from the exhaust using a contact cleaner (or other non flammable cleaner). Fingerprints will leave stains on the pipe once the motorcycle is started.
11. You are now ready to start the motorcycle.

For best results, we recommend fuel injection mapping for your new combination using a Fuelpak or Power Commander. Settings for the Fuelpak and some Power Commander maps are available on our website at www.vhmotorsports.com

Vance & Hines Motorsports

1211 Northfield Drive, Brownsburg, IN 46112

Tel: (317) 852-9057 Fax: (317) 852-8954

E-mail: tech@vhmotorsports.com

Web: www.vhmotorsports.com

Opening Hours – Monday through Friday, 8am – 5pm, Eastern Standard Time

Due to the nature of high performance racing products and services, Vance & Hines Motorsports products are sold without any express warranty or any implied warranty of fitness for a specific purpose. Vance & Hines Motorsports shall not, under any circumstances, be liable for any special, incidental or consequential damages including, but not limited to, damage or loss which may arise from sale, installation or use of this product.

75-106-4 V-ROD, OUTLAW 2:1 EXHAUST SYSTEM



75-106-4 PARTS LIST		75-106-4 /QTY.
PartNo	DESCRIPTION	
7-50046	Megaphone/Baffle Assy.	1
7-80116	Front Pipe Assy.	1
7-80117	Rear Pipe Assy.	1
7-30002	Spring	4
7-70007	O ₂ Sensor Plug	2
7-70036	Rivet	2
7-50044	Name Plate	1
7-30004	Exhaust Spring Puller Tool	1
7-60030	Indy Series Baffle Assy. 10 1/2" TVD-DPD	1

DRAG SPECIALTIES PART#: 1800-0881

STOCK EXHAUST: 38 lbs
75-106-4: 8 lbs

